




J SCHATZ EGG BIRD FEEDERS®

User Guide



INTRODUCTION

Your new Egg Bird Feeder is easy to use. Please use this User Guide to:


Assemble and fill the Egg Bird Feeder with bird food

Disassemble and refill the Egg Bird Feeder with bird food

EGG BIRD FEEDER PARTS

Your Egg Bird Feeder consists of 5 individual Parts.


1 Stoneware Egg with Vinyl Coated
Hanging Wire



1 Aluminum Base



2 Aluminum Poles




1 Hitch Pin



EGG BIRD FEEDER ASSEMBLY INSTRUCTIONS

STEP 1


Turn the egg upside down and fill with bird food.



EGG BIRD FEEDER ASSEMBLY INSTRUCTIONS

STEP 2


Position the base upside down in the center of the egg and line up the upper holes on the exterior of the egg with the upper holes on the interior of the base. Insert aluminum poles through the egg and base - one pole through the upper holes and one through the lower holes.



EGG BIRD FEEDER ASSEMBLY INSTRUCTIONS

STEP 3


Line up the holes in the aluminum poles and insert the hitch pin through the holes to secure the base in place. Turn the Egg Bird Feeder over and hang.



EGG BIRD FEEDER DISASSEMBLY INSTRUCTIONS

STEP 1


Turn the egg upside down and remove the hitch pin.



EGG BIRD FEEDER DISASSEMBLY INSTRUCTIONS

STEP 2


Remove the aluminum poles from both upper and lower sides of the egg.



EGG BIRD FEEDER DISASSEMBLY INSTRUCTIONS


STEP 3

Remove the base and follow the Assembly Instructions to refill with bird food.



EGG BIRD FEEDER HANGING GUIDE

Hang the Egg Bird Feeder 3' from surrounding surfaces to prevent animals from eating from the feeder. Most animals will not be able to jump onto the slippery surface of the Egg Bird Feeder if hung at least 3' from surrounding surfaces. The Egg Bird Feeder hanging wire is 12" and will need to be connected to an additional length of wire to hang 3' from surrounding surfaces. We recommend using a snap hook to attach the Egg Bird Feeder to the additional length of wire. A snap hook allows the Egg Bird Feeder to easily be removed for refilling. Snap hooks can be found in most hardware stores.



Wonder-Certified™

Your J Schatz product is Wonder-Certified. All J Schatz products are incorporated into Jim's daily life and subjected to the wonder test to become a wonder-certified J Schatz product. The wonder test is quite simple. If a product inspires wonder throughout the weeks, months and years that Jim lives with it, the product will be produced.

About J Schatz

We at J Schatz are dreamers and explorers. Working from our studio in upstate New York, Jim and the team take inspired ideas and create ceramic ware that is pierced, scratched, carved, drilled, glazed and fired into beautifully finished products. All products are created to fit in harmony with the environment. We employ local artists, use energy-saving production methods, and our packaging contains 80% recycled content. Each product leaves our studio beautifully finished, complete with a 100% satisfaction guarantee. Indulge in a moment of wonder with a J Schatz product today.

CUSTOMER SERVICE CALL 866-344-5267

Weekdays 9a.m. - 5p.m. EST

EMAIL CUSTOMERSERVICE@JSCHATZ.COM

OR VISIT WWW.JSCHATZ.COM

Like us on Facebook: www.facebook.com/pages/J-Schatz/75559302135

Egg Bird Feeders, Wonder-Certified, and J Schatz are trademarks of The Office Of Jim Schatz, Inc. Egg Bird Feeders are protected under U.S. Patent #D566,344. ©2011 J Schatz. All Rights Reserved.